



DEALER REFERENCE LIST

IMPORTANT: See the machine parts manual for related parts.

IMPORTANT: Parts are the same for GEN:1, GEN:2, Series I and Series II, E and non E series, EU, SX, SXT, DX, DXT machines unless noted. See the machine parts manual for related parts.

Keys and Ignition Switch - Skid Loader
Quick Reference List

IMPORTANT: If multiple keys possible, use photos on last two pages to help determine which key to order. Parts are not interchangeable.

Model	Serial Number	Ignition Switch	Key Only	Cab Door Key	Notes
R-Series					
R135		272578	50280186	50280186	272578 includes one of key 50280186 and one of Key Cover 50280187. Key 50280186 sold individually (one per purchase). Key 50280186 does not include Key Cover 50280187.
R150		272578	50280186	50280186	
R165		272578	50280186	50280186	
R190	171877 and Up, (plus 171832 - 171839, 171842 and 171844, 171853 - 171856, 171860 - 171863, 171865 - 171866, 171869 - 171873, and 171875)	272578	50280186	50280186	



DEALER REFERENCE LIST

IMPORTANT: See the machine parts manual for related parts.

IMPORTANT: Parts are the same for GEN:1, GEN:2, Series I and Series II, E and non E series, EU, SX, SXT, DX, DXT machines unless noted. See the machine parts manual for related parts.

Keys and Ignition Switch - Skid Loader
Quick Reference List

IMPORTANT: If multiple keys possible, use photos on last two pages to help determine which key to order. Parts are not interchangeable.

Model	Serial Number	Ignition Switch	Key Only	Cab Door Key	Notes
R190	171876 and Before, (except 171832 - 171839, 171842 and 171844, 171853 - 171856, 171860 - 171863, 171865 - 171866, 171869 - 171873, and 171875)	195087	073694	243561 or 50280186	195087 includes 2 of 073694. Keys 243561 and 50280186 are not interchangeable.
R220	173975 and Up (plus 173935 and 173937 - 173938 and 173941, 173946 - 173947, 173958 - 173967)	272578	50280186	50280186	272578 includes one of key 50280186 and one of Key Cover 50280187. Key 50280186 sold individually (one per purchase). Key 50280186 does not include Key Cover 50280187.
R220	173974 and Before (except 173935 and 173937 - 173938, and 173941, 173946 - 173947, 173958 - 173967)	195087	073694	243561 or 50280186	195087 includes 2 of 073694. Keys 243561 and 50280186 are not interchangeable.



DEALER REFERENCE LIST

IMPORTANT: See the machine parts manual for related parts.

IMPORTANT: Parts are the same for GEN:1, GEN:2, Series I and Series II, E and non E series, EU, SX, SXT, DX, DXT machines unless noted. See the machine parts manual for related parts.

Keys and Ignition Switch - Skid Loader
Quick Reference List

IMPORTANT: If multiple keys possible, use photos on last two pages to help determine which key to order. Parts are not interchangeable.

Model	Serial Number	Ignition Switch	Key Only	Cab Door Key	Notes
R260	175851 and Up (plus 175846 - 175848)	272578	50280186	50280186	272578 includes one of key 50280186 and one of Key Cover 50280187. Key 50280186 sold individually (one per purchase). Key 50280186 does not include Key Cover 50280187.
R260	175850 and Before (except 175846 - 175848)	195087	073694	243561 or 50280186	195087 includes 2 of 073694. Keys 243561 and 50280186 are not interchangeable.

V-Series

V270	23412 and Up	272578	50280186	50280186	272578 includes one of key 50280186 and one of Key Cover 50280187. Key 50280186 sold individually (one per purchase). Key 50280186 does not include Key Cover 50280187.
V270	23411 and Before	195087	073694	243561 or 50280186	195087 includes 2 of 073694. Keys 243561 and 50280186 are not interchangeable.



IMPORTANT: See the machine parts manual for related parts.

IMPORTANT: Parts are the same for GEN:1, GEN:2, Series I and Series II, E and non E series, EU, SX, SXT, DX, DXT machines unless noted. See the machine parts manual for related parts.

DEALER REFERENCE LIST

Keys and Ignition Switch - Skid Loader
Quick Reference List

IMPORTANT: If multiple keys possible, use photos on last two pages to help determine which key to order. Parts are not interchangeable.

Model	Serial Number	Ignition Switch	Key Only	Cab Door Key	Notes
V330	133292 and Up	272578	50280186	50280186	272578 includes one of key 50280186 and one of Key Cover 50280187. Key 50280186 sold individually (one per purchase). Key 50280186 does not include Key Cover 50280187.
V330	133291 and Before	195087	073694	243561 or 50280186	195087 includes 2 of 073694. Keys 243561 and 50280186 are not interchangeable.
V400	151863 and Up (plus 151856 - 151860)	272578	50280186	50280186	272578 includes one of key 50280186 and one of Key Cover 50280187. Key 50280186 sold individually (one per purchase). Key 50280186 does not include Key Cover 50280187.
V400	151862 and Before (except 151856 - 151860)	195087	073694	243561 or 50280186	195087 includes 2 of 073694. Keys 243561 and 50280186 are not interchangeable.

SL-Series

1640		195087	073694	243561 or 50280186	195087 includes 2 of 073694. Keys 243561 and 50280186 are not interchangeable.
3310		072808	073694	N/A	072808 includes 2 of 073694



DEALER REFERENCE LIST

IMPORTANT: See the machine parts manual for related parts.

IMPORTANT: Parts are the same for GEN:1, GEN:2, Series I and Series II, E and non E series, EU, SX, SXT, DX, DXT machines unless noted. See the machine parts manual for related parts.

Keys and Ignition Switch - Skid Loader
Quick Reference List

IMPORTANT: If multiple keys possible, use photos on last two pages to help determine which key to order. Parts are not interchangeable.

Model	Serial Number	Ignition Switch	Key Only	Cab Door Key	Notes
3410		078208 switch and 078209 cylinder	088497	N/A	078208, 078209, and 088497 must all be purchased separately.
3510		072808	073694	N/A	072808 includes 2 of 073694
3515		072808	073694	N/A	072808 includes 2 of 073694
3610	2001 and Up	078208 switch and 078209 cylinder	088497	N/A	078208, 078209, and 088497 must all be purchased separately.
3610	2000 and Before	072808	073694	N/A	072808 includes 2 of 073694
3615		078208 switch and 078209 cylinder	088497	N/A	078208, 078209, and 088497 must all be purchased separately.
3635		131688	131748	420-35399	131688 includes 2 of 131748
3640		195087	073694	420-35399	195087 includes 2 of 073694
3725	7409 and Up	131688	131748	096822	
3725	7351 - 7408	089069	089070	096822	
3725	6320 - 7350	089069	089070	096822	Keys / switches do not interchange, visually confirm which combination the machine uses before ordering.
3725	6320 - 7350	124099	124098	096822	
3725	6319 and Before	123022 (OBS) - see note	123023	096822	Switch 123022 is no longer available. For replacement order Switch 124099, and Key 124098. Key 123023 only works with switch 123022.



DEALER REFERENCE LIST

IMPORTANT: See the machine parts manual for related parts.

IMPORTANT: Parts are the same for GEN:1, GEN:2, Series I and Series II, E and non E series, EU, SX, SXT, DX, DXT machines unless noted. See the machine parts manual for related parts.

Keys and Ignition Switch - Skid Loader
Quick Reference List

IMPORTANT: If multiple keys possible, use photos on last two pages to help determine which key to order. Parts are not interchangeable.

Model	Serial Number	Ignition Switch	Key Only	Cab Door Key	Notes
3725	6319 and Before	089069	089070	096822	Keys / switches do not interchange, visually confirm which combination the machine uses before ordering.
3725	6319 and Before	124099	124098	096822	
3825	11089 and Up	131688	131748	096822	Keys / switches do not interchange, visually confirm which combination the machine uses before ordering.
3825	10701 - 11088	089069	089070	096822	
3825	8589 - 10700	089069	089070	096822	Keys / switches do not interchange, visually confirm which combination the machine uses before ordering.
3825	8589 - 10700	124099	124098	096822	
3825	8588 and Before	123022 (OBS) - see note	123023	096822	Switch 123022 is no longer available. For replacement order Switch 124099, and Key 124098. Key 123023 only works with switch 123022.
3825	8588 and Before	089069	089070	096822	Keys / switches do not interchange, visually confirm which combination the machine uses before ordering.
3825	8588 and Before	124099	124098	096822	
3935		131688	131748	420-35399	131688 includes 2 of 131748
4240		195087	073694	420-35399	195087 includes 2 of 073694
4300		054944	058830	N/A	054944 includes 1 of 058830



DEALER REFERENCE LIST

IMPORTANT: See the machine parts manual for related parts.

IMPORTANT: Parts are the same for GEN:1, GEN:2, Series I and Series II, E and non E series, EU, SX, SXT, DX, DXT machines unless noted. See the machine parts manual for related parts.

Keys and Ignition Switch - Skid Loader
Quick Reference List

IMPORTANT: If multiple keys possible, use photos on last two pages to help determine which key to order. Parts are not interchangeable.

Model	Serial Number	Ignition Switch	Key Only	Cab Door Key	Notes
4500		054944	058830	N/A	054944 includes 1 of 058830
4510		072808	073694	096822	072808 includes 2 of 073694
4515		072808	073694	096822	072808 includes 2 of 073694
4610		072808	073694	096822	072808 includes 2 of 073694
4615		072808	073694	096822	072808 includes 2 of 073694
4525	8563 - 9119	089069	089070	096822	Keys / switches do not interchange, visually confirm which combination the machine uses before ordering.
4525	8563 - 9119	124099	124098	096822	
4525	8562 and Before	123022 (OBS) - see note	123023	096822	Switch 123022 is no longer available. For replacement order Switch 124099, and Key 124098. Key 123023 only works with switch 123022.
4525	8562 and Before	089069	089070	096822	Keys / switches do not interchange, visually confirm which combination the machine uses before ordering.
4525	8562 and Before	124099	124098	096822	
4625	22889 and Up	131688	131748	096822	
4625	21907 - 22889	089069	089070	096822	
4625	17214 - 21906	089069	089070	096822	Keys / switches do not interchange, visually confirm which combination the machine uses before ordering.
4625	17214 - 21906	124099	124098	096822	



DEALER REFERENCE LIST

IMPORTANT: See the machine parts manual for related parts.

IMPORTANT: Parts are the same for GEN:1, GEN:2, Series I and Series II, E and non E series, EU, SX, SXT, DX, DXT machines unless noted. See the machine parts manual for related parts.

Keys and Ignition Switch - Skid Loader
Quick Reference List

IMPORTANT: If multiple keys possible, use photos on last two pages to help determine which key to order. Parts are not interchangeable.

Model	Serial Number	Ignition Switch	Key Only	Cab Door Key	Notes
4625	17213 and Before	123022 (OBS) - see note	123023	096822	Switch 123022 is no longer available. For replacement order Switch 124099, and Key 124098. Key 123023 only works with switch 123022.
4625	17213 and Before	089069	089070	096822	Keys / switches do not interchange, visually confirm which combination the machine uses before ordering.
4625	17213 and Before	124099	124098	096822	
4635		131688	131748	096822	131688 includes 2 of 131748
4640	307901 and Up	195087	073694	420-35399	195087 includes 2 of 073694
4640	307900 and Before	131688	131748	420-35399	131688 includes 2 of 131748
4700		054944	058830	N/A	054944 includes 1 of 058830
4835		131688	131748	096822	131688 includes 2 of 131748
4840	408501 and Up	195087	073694	420-35399	195087 includes 2 of 073694
4840	408500 and Before	131688	131748	420-35399	131688 includes 2 of 131748
5240		195087	073694	420-35399	195087 includes 2 of 073694
5620		089069	089070	096822	089069 includes 2 of 089070
5625	11243 and Up	131688	131748	096822	131688 includes 2 of 131748
5625	11242 and Before	089069	089070	096822	089069 includes 2 of 089070
5635	Series I and II	131688	131748	096822	131688 includes 2 of 131748
5640	506601 and Up	195087	073694	420-35399	195087 includes 2 of 073694
5640	506600 and Before	131688	131748	420-35399	131688 includes 2 of 131748
6620		072808	073694	096822	072808 includes 2 of 073694



DEALER REFERENCE LIST

IMPORTANT: See the machine parts manual for related parts.

IMPORTANT: Parts are the same for GEN:1, GEN:2, Series I and Series II, E and non E series, EU, SX, SXT, DX, DXT machines unless noted. See the machine parts manual for related parts.

Keys and Ignition Switch - Skid Loader
Quick Reference List

IMPORTANT: If multiple keys possible, use photos on last two pages to help determine which key to order. Parts are not interchangeable.

Model	Serial Number	Ignition Switch	Key Only	Cab Door Key	Notes
6625	7605 and Up	089069	089070	096822	089069 includes 2 of 089070
6625	7604 and Before	072808	073694	096822	072808 includes 2 of 073694
6635	Series I and II	131688	131748	096822	131688 includes 2 of 131748
6640	605501 and Up	195087	073694	420-35399	195087 includes 2 of 073694
6640	605500 and Before	131688	131748	420-35399	131688 includes 2 of 131748
7600		131688	131748	L99157	131688 includes 2 of 131748
7610		131688	131748	L99157	131688 includes 2 of 131748
7800		131688	131748	L99157	131688 includes 2 of 131748
7810	903001 to 904501	131688	131748	L99157	131688 includes 2 of 131748
7810E	904502 and Up	195087	073694	L99157	195087 includes 2 of 073694

Notes:



DEALER REFERENCE LIST

IMPORTANT: See the machine parts manual for related parts.

IMPORTANT: Parts are the same for GEN:1, GEN:2, Series I and Series II, E and non E series, EU, SX, SXT, DX, DXT machines unless noted. See the machine parts manual for related parts.

Keys and Ignition Switch - Skid Loader
Quick Reference List

IMPORTANT: If multiple keys possible, use photos on last two pages to help determine which key to order. Parts are not interchangeable.

Ignition Key Comparisons

50280186



50280186 - Sold Individually

131748

124098

089070

123023

073694

NOTE: The above five keys are all sold in pairs. Photos not to scale.



DEALER REFERENCE LIST

IMPORTANT: See the machine parts manual for related parts.

IMPORTANT: Parts are the same for GEN:1, GEN:2, Series I and Series II, E and non E series, EU, SX, SXT, DX, DXT machines unless noted. See the machine parts manual for related parts.

Keys and Ignition Switch - Skid Loader
Quick Reference List

IMPORTANT: If multiple keys possible, use photos on last two pages to help determine which key to order. Parts are not interchangeable.

243561 and 50280186 Cab Door Key Kit Comparison





DEALER REFERENCE LIST

IMPORTANT: See the machine parts manual for related parts.

IMPORTANT: Parts are the same for GEN:1, GEN:2, Series I and Series II, E and non E series, EU, SX, SXT, DX, DXT machines unless noted. See the machine parts manual for related parts.

Keys and Ignition Switch - Skid Loader
Quick Reference List

IMPORTANT: If multiple keys possible, use photos on last two pages to help determine which key to order. Parts are not interchangeable.

Notes: